

## Step-by-step guide

## Setting up the Live Streamer CAM 313 with Skype

What you need:

- Live Streamer CAM 313
- USB port
- Desktop or laptop computer
- Skype

In the search box on the taskbar, type **Device Manager**, then select from the menu:

- Cameras -> Live Streamer CAM 313
- Sound, video and game controllers -> Live Streamer CAM 313 Microphone

Device Manager
File Action View Help
V 🗄 DESKTOP-RQKH5L6
> I Audio inputs and outputs
🕐 👰 Cameras
Q Live Streamer CAM 313
> 💻 Computer
> 🔜 Disk drives
> 🏣 Display adapters
> 🐺 Human Interface Devices
> 📹 IDE ATA/ATAPI controllers
> 🔤 Keyboards
> III Mice and other pointing devices
> 💻 Monitors
> 🖵 Network adapters
> 📮 Ports (COM & LPT)
🗸 🚍 Print queues
📇 Fax
🚍 Microsoft Print to PDF
🚍 Microsoft XPS Document Writer
📇 OneNote for Windows 10
📑 Root Print Queue
Processors
Software devices
Sound, video and game controllers
Live Streamer CAM313 Microphone
NVIDIA High Definition Audio
Realtek High Definition Audio
VB-Audio VoiceMeeter AUX VAIO
VB-Audio VoiceMeeter VAIO
> Storage controllers
> 🏣 System devices
> 🏺 Universal Serial Bus controllers

To set your default output speaker, please do the following:

- 1. Open Settings
- 2. Click on System
- 3. Click on Sound


The Sound page includes two sections separating the output and input options:

In the section that states "**Choose your output device**" select the speaker option that suits your needs. If none are available in the dropdown, it will default to your standard speaker settings.

In the section that states, "**Choose your input device**", select the "Microphone (Live Streamer CAM 313 MIC)" to begin using the Live Streamer CAM313.

Settings	×
ம் Home	Sound
Find a setting	A Manage sound devices
System	
🖵 Display	Input Choose your input device
다) Sound	Microphone (Live Streamer CAM313 $$
Notifications & actions	Certain apps may be set up to use different sound devices than the one selected here. Customize app volumes and devices in advanced sound options.
J Focus assist	Device properties
( <sup>1</sup> ) Power & sleep	Test your microphone
Storage	
곱 Tablet mode	Manage sound devices

Launch Skype, click the "..." (Ellipsis button) on the corner. Select "**Settings**" to view the Audio Settings window.



Click "Audio & Video Settings" and then click the "Live Streamer CAM 313" in the drop-down box and select it.

• • •	Skype	
	VIDEO	
Settings	Camera	Live Streamer CAM 313 $\sim$
Account & Profile		
දිරි} General		
Appearance		
🔱 Audio & Video		
& Calling		
三 Messaging	Choose background e	effect
D Notifications	None Blur	+ Add image
Contacts	AUDIO	
i Help & Feedback		Live Streamer CAM313 Microphone ~